



#### INSTRUCTIONS:

1. FOLD TEMPLATE AND PLACE INTO POSITION.
2. MARK STRIKE CENTER HOLE ON DOOR AND THE TWO (2) SLOTTED LOCK MOUNTING BRACKET HOLES ON THE DOOR FRAME.
3. PLEASE REFER TO THE INSTALLATION INSTRUCTIONS PROVIDED WITH THE LOCK FOR COMPLETE STRIKE INSTALLATION DETAILS. THEN DRILL THE THREE (3) HOLES AND INSTALL THE STRIKE TO THE DOOR USING THE HARDWARE PROVIDED.  
**NOTE:** WHEN INSERTING SEX BOLT FROM OUTSIDE OF THE DOOR, DO NOT FULLY INSERT UNTIL MATING SCREW HAS BEEN STARTED FROM THE OTHER SIDE. THIS ENSURES THAT THE SEX BOLT WILL GO IN STRAIGHT. DO NOT OVERTIGHTEN THE SCREW/SEX BOLT.
4. FOR METAL DOOR FRAME: DRILL TWO (2) 3/8" [9,5] DIA. HOLES THROUGH DOOR FRAME AND INSTALL TWO (2) BLIND NUTS.  
FOR WOOD DOOR FRAME: DRILL TWO (2) 3/16" [4,8] DIA. HOLES X 1-1/4" [31,8] DEEP (MIN.).
5. MARK AND DRILL 1/2" [12,7] DIA. HOLE THRU FRAME WITHIN EITHER OF THE OBOUND SLOTS OF THE BRACKET TO PROVIDE FOR WIRE FEED THROUGH TO LOCK.
6. INSTALL MOUNTING BRACKET TO METAL FRAME BY INSERTING TWO (2) 1/4"-20 UNC MACHINE SCREWS PROVIDED THROUGH MOUNTING BRACKET AND THREAD INTO BLIND NUTS.  
INSTALL MOUNTING BRACKET TO WOOD FRAME BY INSERTING TWO (2) #12 TYPE "A" SCREWS PROVIDED THROUGH MOUNTING BRACKET AND INTO HOLES.  
(TIGHTEN TO "SNUG" BUT NOT SECURE - ALLOW FREE MOVEMENT IN BRACKET SLOTS).

7. ASSEMBLE THE LOCK ONTO THE MOUNTING BRACKET BY ENGAGING THE DOVETAIL AND SLIDING INTO PLACE.
8. ADJUST LOCK/BRACKET INTO PROPER POSITION (AGAINST STRIKE).
9. CAREFULLY REMOVE LOCK FROM BRACKET AND SECURE (FULLY TIGHTEN) THE TWO (2) SCREWS INSTALLED IN STEP 6.
10. USING THE BRACKET AS A GUIDE, CENTER PUNCH THE FRAME AT THE REMAINING THREE (3) HOLES IN THE BRACKET, THEN COMPLETE INSTALLATION AS FOLLOWS:  
FOR METAL DOOR FRAME: DRILL THREE (3) 3/16" [4,8] DIA. HOLES (THRU).  
FOR WOOD DOOR FRAME: DRILL THREE (3) 7/32" [5,5] DIA. HOLES X 2-3/4" [69,9] DEEP (MIN.).
11. SECURE MOUNTING BRACKET TO FRAME USING THREE (3) TYPE "A" SCREWS PROVIDED. (SEE SECTION 5.2.2 "DOOR FRAME PREPARATION" FIGURES 3 AND 4 IN INSTALLATION AND OPERATING INSTRUCTION MANUAL).
12. ASSEMBLE (SLIDE) LOCK ONTO MOUNTING BRACKET AND SECURE INTO PLACE BY TIGHTENING DIAGONAL SET SCREWS USING 1/16" HEX (ALLEN) WRENCH PROVIDED.

DO NOT PHOTOCOPY TEMPLATE  
(scale may be affected)

**SECURITRON®**  
**ASSA ABLOY**  
**TEMPLATE**  
**FOR M38 LOCK**

P/N 500-20280-D