TEMPLATE FOR 62F SERIES MAGNALOCK (FACE MOUNT)

!!! WARNING: DO NOT DRILL INTO MAGNET OR STRIKE FOR ANY REASON !!!

- 1. See installation instructions and Z-Bracket instructions for full information and troubleshooting.
- 2. The relationship between the four magnet mounting holes is critical. Do not let your marking or drilling wander.
- 3. Do not overdrill the diameter of the 3/8" [9.5mm] magnet mounting holes or the blind nuts will not seat. It is best to use a center punch to create indentations for all drill locations.
- 4. Do not over tighten the magnet mounting screws. Use provided LOCTITE on screw threads.
- 5. The two rubber washers stack one on top of the other and mount in between the strike and the Z-Bracket around the center strike mounting screw. Do not place the washers on the roll pins.
- 6. Make sure the strike plate floats and pivots around the center mounting screw. This compensates for door misalignment. If the strike is mounted rigidly, the Magnalock will not hold.
- 7. Use of roll pin plastic bushings is recommended on metal doors. If the plastic bushings are not used, drill 3/8" [9.5mm] diameter holes for the strike roll pins.
- 8. DO NOT PHOTOCOPY TEMPLATE (dimensions will change).





